


# Presence Sensor

## Installation Manual



# Table of contents

- [Presence Sensor](#)
- [Table of contents](#)
  - [1. Presence Sensor Features](#)
    - [1.1. Security](#)
  - [2. General information](#)
    - [2.1. Document Version information](#)
    - [2.2. Used Terms](#)
    - [2.3. Safety instructions](#)
    - [2.4. Issues](#)
    - [2.5. Contact information](#)
  - [3. Technical Information](#)
    - [3.1. Storage Conditions](#)
    - [3.2. Operating Conditions](#)
    - [3.3. Sensor information](#)
      - [3.3.1. Sensor Measurement Ranges](#)
      - [3.3.2. Sensor Accuracy](#)
      - [3.3.3. Ceiling Detection performance](#)
      - [3.3.4. Wall Detection performance](#)
      - [3.3.5. Typical Luminance](#)
    - [3.4. Radio Specification](#)
  - [4. Physical placement of the Presence Sensor](#)
    - [4.1. Ceiling mounting](#)
    - [4.2. Wall mounting](#)
    - [4.3. Device size](#)
  - [5. Configuration](#)
    - [5.1. Device Startup](#)
    - [5.2. Commissioning](#)
      - [5.2.1. Thread Commissioning](#)
      - [5.2.2. KNX Commissioning](#)
        - [5.2.2.1. Channels](#)
        - [5.2.2.2. Movement Coordination](#)
        - [5.2.2.3. Downloading the ETS configuration](#)
          - [5.2.2.3.1. Reset of the Presence Sensor](#)
  - [6. Software Bill of Materials](#)
    - [6.1. Cascoda SDK](#)
    - [6.2. tinycbor](#)
    - [6.3. mbedtls](#)
    - [6.4. Openthread](#)

- [7. KNX device information](#)
  - [7.1. Data points](#)
    - [7.1.1. On/Off 1](#)
    - [7.1.2. Presence 1](#)
    - [7.1.3. Scene 1](#)
    - [7.1.4. HVAC mode 1](#)
    - [7.1.5. Switch On/Off 1](#)
    - [7.1.6. Scaling 1](#)
    - [7.1.7. RGB On/Off 1](#)
    - [7.1.8. RGB 1](#)
    - [7.1.9. On/Off 2](#)
    - [7.1.10. Presence 2](#)
    - [7.1.11. Scene 2](#)
    - [7.1.12. HVAC mode 2](#)
    - [7.1.13. Switch On/Off 2](#)
    - [7.1.14. Scaling 2](#)
    - [7.1.15. RGB On/Off 2](#)
    - [7.1.16. RGB 2](#)
    - [7.1.17. Luminance 4](#)
    - [7.1.18. Battery Information 3](#)
    - [7.1.19. Battery Information \(percentage\) 3](#)
    - [7.1.20. Battery Alarm 3](#)
    - [7.1.21. RSSI 3](#)
  - [7.2. Parameters](#)
    - [7.2.1. Parameter Switch On delay 1](#)
    - [7.2.2. Parameter Switch Off Delay 1](#)
    - [7.2.3. Parameter Luminance Level 1](#)
    - [7.2.4. Parameter EBI 1](#)
    - [7.2.5. Parameter Luminance Level 2 1 1](#)
    - [7.2.6. Parameter Luminance Level 2 2 1](#)
    - [7.2.7. Parameter Luminance Level 3 1 1](#)
    - [7.2.8. Parameter Luminance Level 3 2 1](#)
    - [7.2.9. Parameter Luminance Level 3 3 1](#)
    - [7.2.10. Parameter Luminance Levels 1](#)
    - [7.2.11. Parameter Scene On 1](#)
    - [7.2.12. Parameter Scene Off 1](#)
    - [7.2.13. Parameter HVAC On 1](#)
    - [7.2.14. Parameter HVAC Off 1](#)
    - [7.2.15. Parameter Scaling On 1](#)
    - [7.2.16. Parameter Scaling On 2 1](#)
    - [7.2.17. Parameter Scaling On 3 1](#)
    - [7.2.18. Parameter Scaling Off 1](#)
    - [7.2.19. Parameter Color On 1](#)

- [7.2.20. Parameter Color Off 1](#)
- [7.2.21. Parameter Luminance Level 2](#)
- [7.2.22. Parameter Luminance Level 2 1 2](#)
- [7.2.23. Parameter Luminance Level 2 2 2](#)
- [7.2.24. Parameter Luminance Level 3 1 2](#)
- [7.2.25. Parameter Luminance Level 3 2 2](#)
- [7.2.26. Parameter Luminance Level 3 3 2](#)
- [7.2.27. Parameter Luminance Levels 2](#)
- [7.2.28. Parameter Scene On 2](#)
- [7.2.29. Parameter Scene Off 2](#)
- [7.2.30. Parameter HVAC On 2](#)
- [7.2.31. Parameter HVAC Off 2](#)
- [7.2.32. Parameter Scaling On 2](#)
- [7.2.33. Parameter Scaling On 2 2](#)
- [7.2.34. Parameter Scaling On 3 2](#)
- [7.2.35. Parameter Scaling Off 2](#)
- [7.2.36. Parameter Color On 2](#)
- [7.2.37. Parameter Color Off 2](#)
- [7.2.38. Parameter On/Off \(luminance\) 4](#)
- [7.2.39. Parameter Sleep Period \(luminance\) 4](#)
- [7.2.40. Parameter Sleep Period \(battery value\) 3](#)
- [7.2.41. Parameter Battery Curve 3](#)
- [7.2.42. Parameter Battery Alarm Level 3](#)

## List of Figures

- Figure 1 : [Ceiling Mount detection area](#)
- Figure 2 : [Wall Mount detection area](#)
- Figure 3 : [The mounting plate](#)
- Figure 4 : [Sequence of steps to install the presence sensor on the mounting plate](#)
- Figure 5 : [Ceiling Mounted presence sensor](#)
- Figure 6 : [Wall Mounted presence sensor](#)
- Figure 7 : [Device sizes, 3d angle](#)
- Figure 8 : [Device size, including mounting plate size](#)
- Figure 9 : [mounting plate sizes](#)
- Figure 10 : [Device without mounting plate, showing the placement of the batteries.](#)
- Figure 11 : [Movement Coordination by means of a logical OR function.](#)

## List of Tables

- Table 1: [Used Terms](#)
- Table 2: [Storage Conditions](#)
- Table 3: [Operating Conditions](#)

- Table 4: [Battery information](#)
- Table 5: [Sensor information](#)
- Table 6: [Sensor Accuracy](#)
- Table 7: [Detection Range for the Ceiling mounted Presence Sensor.](#)
- Table 8: [Detection Range for the Wall mounted Presence Sensor.](#)
- Table 9: [Typical luminance values](#)
- Table 10: [Thread Radio Information](#)
- Table 11: [Inputs \(A and B\) for a logical OR function with the corresponding Output.](#)
- Table 12: [Software Bill of Materials](#)
- Table 13: [Data points](#)
- Table 14: [Parameters](#)

# 1. Presence Sensor Features

Cascoda's KNX IoT Presence Sensor provides presence/movement sensing.

- The presence sensor detects movement of people, even when there is little movement.
- Includes Brightness sensor (in Lux).
- Mixed light measurement (daylight and artificial light)
- Battery powered, install anywhere!

There are 2 variants:

- Low profile ceiling installation, 360 degrees detection.
- Low profile wall installation, 170 degrees detection.

Measures the following environmental variables:

- Presence (PIR), Passive or pyroelectric infrared (PIR) sensors are thermal detectors and suitable as motion sensors. They react to a change in infrared heat radiation in the environment. Reliable detection: small temperature difference between the background (e.g. floor / wall) and the target object (human).
- Luminance

This sensor is the perfect choice for environments where the smallest of movements need to be detected, e.g. B. in offices, waiting rooms, wellness rooms, sanitary areas, and many more. The sensor can reliably detect people walking in a distance of up to 6m, which is typical for reception rooms or warehouses, to name just a few.

Other features:

- Wireless Thread, sleepy end device, using Chili2S with Industry leading receive sensitivity
- Battery charge status indicator for any chemistry.
- Configurable with ETS6.3 or later

Specification:

- Wall or panel mount options
- Dimensions 78 x 78 x 26 mm
- Battery powered (3 AA)
- 5-year battery life on Alkaline (LR6)
- 6-year battery life on Lithium (FR6)

## 1.1. Security



This KNX device support the latest KNX IoT standard. This extension of the KNX enables fully encrypted transmission of data telegrams, thus ensuring secure data- and access-proof communication between KNX devices within a single installation. The KNX-specific Engineering Tool Software (ETS) secures both the runtime communication over IP as well as commissioning. This device certificate key, imprinted as a QR code for fast identification, allows the ETS to authenticate the device and perform the Secure commissioning.

## 2. General information

### 2.1. Document Version information

This manual is amended periodically and will be brought into line with new software releases. The change status (date) can be found in the contents header. If you have a device with a later software version, please check [www.cascoda.com](http://www.cascoda.com) to find out whether a more up-to date version of the manual is available.

### 2.2. Used Terms

Sign	Description
<b>DANGER!</b>	Indicates an immediately hazardous situation which will lead to death or severe injuries if it is not avoided.
<b>CAUTION!</b>	Indicates a potentially hazardous situation which may lead to trivial or minor injuries if it is not avoided.
<b>WARNING!</b>	Indicates a situation which may lead to damage to property if it is not avoided.
<b>NOTE!</b>	Indicates a situation which may lead to possible (known) side effects.

*Table 1: Used Terms*

### 2.3. Safety instructions

**CAUTION!** Risk of explosion if an incorrect battery is installed. Use consumer grade, non-rechargeable alkaline, zinc-carbon or lithium batteries.

**CAUTION!** The product is only suitable for mounting at heights of less or equal than 2 meters.

### 2.4. Issues

Questions about the product?

You can reach the technical service of Cascoda under Tel. +44 (0)2380 638 111 or [support@cascoda.com](mailto:support@cascoda.com).

We need the following information to process your service request:

- Type of appliance (model name or item number)
- Description of the problem
- Serial number or software version
- Source of supply (dealer/installer who bought the device from Cascoda )

For questions about KNX functions:

- Version of the device application
- ETS version used for the project

## 2.5. Contact information

info@cascodea.com

Threefield House,

Threefield Lane,

Southampton,

SO14 3LP, UK

## 3. Technical Information

### 3.1. Storage Conditions

Parameter	Min	Typ	Max	Unit
Storage Temperature	-25		70	°C
Storage Humidity	0		65	%RH

**Table 2:** Storage Conditions

### 3.2. Operating Conditions

Parameter	Min	Typ	Max	Unit
Operating Temperature	0		50	°C
Supply Voltage	3.1	4.5	5.5	V

**Table 3:** Operating Conditions

The device is supplied by 3x 1.5V AA Batteries (LR6 or FR6), non-rechargeable.

Parameter	Condition	Min	Typ	Max	Unit
Wakeup Interval			60		Minutes
Battery Life	LR6 Alkaline			5	Years
	FR6 Lithium			6	Years

**Table 4:** Battery information

### 3.3. Sensor information

#### 3.3.1. Sensor Measurement Ranges

Parameter	Min	Typ	Max	Unit
Luminance	0		20000	Lux

**Table 5:** Sensor information

#### 3.3.2. Sensor Accuracy


Parameter	Condition	Absolute Accuracy	RMS Noise	Unit
Luminance	Over entire Range	±0.4	0.03	Lux

**Table 6:** Sensor Accuracy

### 3.3.3. Ceiling Detection performance

Detection Area	Value
Horizontal	102°(±51°)
Vertical	92°(±46°)

**Table 7:** Detection Range for the Ceiling mounted Presence Sensor.



**Fig 1:** Ceiling Mount detection area

	Temperature Difference	Value
Detection Range	4°C Δ	up to 12 m
	8°C Δ	up to 17 m

**Table 8:** Detection Range for the Wall mounted Presence Sensor.

Typical conditions of the detected target:

- Movement speed: 1.0m/s

- Human body (size 700x250 mm)
- Using 92 detection zones

### 3.3.4. Wall Detection performance

Detection Area	Value
Horizontal	105°(±52.5°)
Vertical	40°




Fig 2: Wall Mount detection area

Lens	Temperature Difference	Range Value
1st Line Lens	4°C Δ	up to 12 m
	8°C Δ	up to 17 m
1nd Line Lens	4°C Δ	up to 6 m
	8°C Δ	up to 8 m
3rd Line Lens	4°C Δ	up to 3 m
	8°C Δ	up to 4 m

Typical conditions of the detected target:

- Movement speed: 1.0m/s
- Human body (size 700x250 mm)
- Cross perpendicularly for the detection zone
- Using 68 detection zones

### 3.3.5. Typical Luminance

Typical luminance values are listed in in the table below.

Condition	lux
Sunlight at noon in summer	100000
Cloudy sky in summer	10000
Rainy weather with thunder clouds	1000
Office lighting	500
Living room lighting	200
Staircase lighting	100
Street lighting	10
Twilight after sunset	1
Midnight at full moon	0,2
Sky with stars and no moon	0,0005

**Table 9:** Typical luminance values

### 3.4. Radio Specification

Protocol: KNX-IoT over Thread

MAC Protocol: IEEE 802.15.4

Configuration: 2.4 GHz, O-QPSK, 250 kbps, Channels 11-26

Parameter	Min	Typ	Max	Unit
Frequency Range	2405		2480	MHz
Transmit Power	0		9	dBm


**Table 10:** Thread Radio Information

## 4. Physical placement of the Presence Sensor

The Presence sensor can measure the presence in a specific place/room. There is a presence sensor for wall mounting or for ceiling mounting. The difference is the range of detection.

Since the device is a radio based device, the device should not be put in a metal surrounding. For example a metal filing cabinet. The device should be in range of its parent (router) node, so that it is able to send the measurements over the Thread network.

To install the Presence sensor the following mounting plate is supplied:



*Fig 3: The mounting plate*

The installation sequence is depicted in the following diagram:




Fig 4: Sequence of steps to install the presence sensor on the mounting plate

## 4.1. Ceiling mounting

To install the Presence sensor the mounting plate should be installed on the ceiling. When the bracket is installed on the ceiling the Presence sensor can be clicked on the the mounting plate.



Fig 5: Ceiling Mounted presence sensor

## 4.2. Wall mounting

To install the Presence sensor the mounting plate should be installed on the wall. The direction of arrows on the mounting plate must be to the ceiling (e.g. "Up"). When the bracket is installed on the wall the Presence sensor can be clicked on the the mounting plate. Then the luminance sensor will be below the Presence sensor.



*Fig 6: Wall Mounted presence sensor*

## 4.3. Device size

The following diagrams are showing the size of the device. The sizes are in [mm].



*Fig 7: Device sizes, 3d angle*




Fig 8: Device size, including mounting plate size




Fig 9: mounting plate sizes

## 5. Configuration

### 5.1. Device Startup

The device will start up when the batteries are inserted. The batteries can be inserted when the device is removed from the mounting plate. The size of batteries are **AA**.



*Fig 10: Device without mounting plate, showing the placement of the batteries.*

## 5.2. Commissioning

Configuration is made using the KNX software as of ETS 6.3 or later. The product file can be downloaded from the ETS online catalogue and the [Cascode website](#). After the batteries has been applied, the device will enter a commissioning phase.

The QR code is placed on the device.

The QR code can be used to for Thread commissioning and KNX commissioning.

**NOTE!** Thread commissioning needs to be done before KNX commissioning, since this enables the IPV6 communication.

### 5.2.1. Thread Commissioning

Thread commissioning is adding the device to the thread network. To be able to do so, one needs to have a Thread Border router. Cascode recommends using the [KNX-IOT-HUB](#)

Check out the youtube video [here](#), demonstrating the process of doing Thread and KNX Commissioning using a QR code scanner.

More information about Thread commissioning can be found [Here](#).

### 5.2.2. KNX Commissioning

KNX commissioning is adding the device to an ETS project. Since KNX IoT is a secure KNX protocol, one needs to have the security credentials and the serial number of the device. This information is contained in the QR code.

The device can only be added to an KNX IoT Area or Line. When the device is added to a KNX IoT area or Line, the credentials can be supplied. ETS can scan the QR code with the camera (or 2D bar code scanner).

Check out the youtube video [here](#), demonstrating the process of doing Thread and KNX Commissioning using a QR code scanner.

#### 5.2.2.1. Channels

The device has 2 channels. The main channel is used to configure the timeouts of the presence detection. The 2nd channel can be used to send additional data points/formats at the same time as the main channel.

#### 5.2.2.2. Movement Coordination


If the lighting in a larger area is controlled by more than one movement detector, then it

shall be avoided that one presence sensor switches the light off, while another presence sensor switches the light on. This can be solved by a not controlling the lighting directly but use the logical OR gate as direct input to the lighting. The logical OR will make sure when one of the presence sensors is indicates "On" that the light is will be turned on. The logical operation OR is depicted in the table below.

Input A	Input B	Output (A OR B)
0	0	0
0	1	1
1	0	1
1	1	1

**Table 11:** Inputs (A and B) for a logical OR function with the corresponding Output.

This means that the movement output can be used as input of the logical function "OR" and the output can be used for switching the light. This is depicted in the figure below.



*Fig 11: Movement Coordination by means of a logical OR function.*

A logical block which includes OR function is implemented in the [KNX IoT Mesh Extender](#).

### 5.2.2.3. Downloading the ETS configuration

The downloading of the configuration can happen when the ETS data for the data is created, e.g.:

- The parameters are set
- The communication objects are connected

The download can be started in ETS, and one can use either:

- download by serial number
- download per programming mode

The download by serial number does not require any interaction with the device, but one has to wait until the sleep period ends.

The download per programming button requires pressing the programming button. The **PROG** button is on the back of the device and needs to be pressed for 1 second. While the **PROG** button is pressed, the LED is on. When the **PROG** button is released and the device is in programming mode the LED above will start flashing. Disabling the programming mode can be achieved by pressing again the **PROG** button.

**NOTE!** Please disable programming mode when not in use, since it consumes extra power.

#### 5.2.2.3.1. Reset of the Presence Sensor

The device allows resetting of KNX and Thread in separate steps. This allows that the KNX configuration can be reset to factory default, without resetting the connectivity part.

- Reset KNX

Reset of KNX is achieved by pressing the **PROG** button for 5 seconds. While the **PROG** button is pressed, the LED is on.

When the **PROG** button is released (after 5 sec), the LED will quickly flash 2 times.

**NOTE!** KNX Reset: this means that also the security credentials are removed. Hence ETS will download newly created device keys.

- Reset Thread

Reset of Thread is achieved by pressing the **PROG** button for 10 seconds. While the **PROG** button is pressed, the LED is on. When the **PROG** button is released (after 10 sec), the LED will slowly flash 3 times.

**NOTE!** Thread Reset: This means that the device needs to be added to the thread network again.

## 6. Software Bill of Materials

This paragraph contains the list of used open source software in this product.

Name	Version	License
Cascoda SDK	0.25	BSD-3-Clause
tinycbor	v0.6.0	MIT
mbedtls	2.16.2	Apache-2.0
Openthread	knx-v1.0.0	BSD-3-Clause

**Table 12:** Software Bill of Materials

### 6.1. Cascoda SDK

- Description: Cascoda development
- License: BSD-3-Clause
- Version: 0.25
- URL: <https://github.com/Cascoda/cascoda-sdk>
- Notes: Chili2D/S SDK, various drivers

### 6.2. tinycbor

- Description: CBOR implementation
- License: MIT
- Version: v0.6.0
- URL: <https://github.com/intel/tinycbor>
- Notes: used for CBOR encoding/decoding

### 6.3. mbedtls

- Description: security constructs
- License: Apache-2.0
- Version: 2.16.2
- URL: <https://github.com/ARMmbed/mbedtls>
- Notes: used for encryption/decryption

### 6.4. Openthread

- Description: OpenThread, IPv6
- License: BSD-3-Clause
- Version: knx-v1.0.0

- URL: <https://github.com/Cascoda/openthread>
- Notes: Cascoda's port of OpenThread

## 7. KNX device information

Info Field	Value
Manufacturer	Cascoda
Model	Presence Sensor
Order_number	0010
Hardware_type	000000000010
Hardware version	[0, 0, 1]
Firmware version	[1, 0, 0]
Sleepy Device	yes
Sleep time (default)	1800

### 7.1. Data points

url	name	instance	resource type	interface type	data type
"/p/1_1"	On/Off 1	1	414.51	if.s	DPT_Switch
"/p/2_1"	Presence 1	1	345.51	if.s	DPT_Occupancy
"/p/3_1"	Scene 1	1	403.61	if.s	DPT_SceneControl
"/p/5_1"	HVAC mode 1	1	397.80	if.s	DPT_HVACMode
"/p/6_1"	Switch On/Off 1	1	420.61	if.s	DPT_Switch
"/p/7_1"	Scaling 1	1	420.63	if.s	DPT_Scaling
"/p/8_1"	RGB On/Off 1	1	424.51	if.s	DPT_Switch
"/p/9_1"	RGB 1	1	424.52	if.s	DPT_Colour_RGB
"/p/1_2"	On/Off 2	1	414.51	if.s	DPT_Switch
"/p/2_2"	Presence 2	1	345.51	if.s	DPT_Occupancy
"/p/3_2"	Scene 2	1	403.61	if.s	DPT_SceneControl
"/p/5_2"	HVAC mode 2	1	397.80	if.s	DPT_HVACMode
"/p/6_2"	Switch On/Off 2	1	420.61	if.s	DPT_Switch
"/p/7_2"	Scaling 2	1	420.63	if.s	DPT_Scaling

url	name	instance	resource type	interface type	data type
"/p/8_2"	RGB On/Off 2	1	424.51	if.s	DPT_Switch
"/p/9_2"	RGB 2	1	424.52	if.s	DPT_Colour_RGB
"/p/l1_4"	Luminance 4	1	409.51	if.s	DPT_Value_Lux
"/p/5d_3"	Battery Information 3	1	443.159	if.s	DPT_Battery_Info
"/p/6d_3"	Battery Information (percentage) 3	1	50004.3077	if.s	DPT_Percent_U8
"/p/7d_3"	Battery Alarm 3	1	50004.3077	if.s	DPT_Alarm
"/p/8d_3"	RSSI 3	1	50004.3078	if.s	DPT_Value_1_Count

**Table 13:** Data points

### 7.1.1. On/Off 1

MDL On/OFF knx:dpa.414.51

### 7.1.2. Presence 1

Occupancy knx:dpa.345.51

### 7.1.3. Scene 1

DPT\_SceneControl knx:dpa.403.61

### 7.1.4. HVAC mode 1

DPT\_HVACMode knx:dpa.397.80

### 7.1.5. Switch On/Off 1

LDSB Switch knx:dpa.420.61

### 7.1.6. Scaling 1

DPT\_Scaling knx:dpa.420.63

### 7.1.7. RGB On/Off 1

CSSRGB Switch knx:dpa.424.51

### 7.1.8. RGB 1

CSSRGB DPT\_ColourRGB [R,G,B] knx:dpa.424.52

### **7.1.9. On/Off 2**

MDL On/OFF knx:dpa.414.51

### **7.1.10. Presence 2**

Occupancy knx:dpa.345.51

### **7.1.11. Scene 2**

DPT\_SceneControl knx:dpa.403.61

### **7.1.12. HVAC mode 2**

DPT\_HVACMode knx:dpa.397.80

### **7.1.13. Switch On/Off 2**

LDSB Switch knx:dpa.420.61

### **7.1.14. Scaling 2**

DPT\_Scaling knx:dpa.420.63

### **7.1.15. RGB On/Off 2**

CSSRGB Switch knx:dpa.424.51

### **7.1.16. RGB 2**

CSSRGB DPT\_ColourRGB [R,G,B] knx:dpa.424.52

### **7.1.17. Luminance 4**

DPT\_Value\_Lux (16bit float)

### **7.1.18. Battery Information 3**

Battery Status knx:dpt.battery\_Info

### **7.1.19. Battery Information (percentage) 3**

Battery Status (percentage)

### **7.1.20. Battery Alarm 3**

## Battery Alarm

### **7.1.21. RSSI 3**

RSSI from Parent

## 7.2. Parameters

url	name	param type
"/p/p1_1"	Switch On delay 1	time
"/p/p2_1"	Switch Off Delay 1	time
"/p/p3_1"	Luminance Level 1	int
"/p/p4_1"	EBI 1	int
"/p/p5_21_1"	Luminance Level 2 1 1	int
"/p/p5_22_1"	Luminance Level 2 2 1	int
"/p/p5_31_1"	Luminance Level 3 1 1	int
"/p/p5_32_1"	Luminance Level 3 2 1	int
"/p/p5_33_1"	Luminance Level 3 3 1	int
"/p/p6_1"	Luminance Levels 1	int
"/p/p7_1"	Scene On 1	int
"/p/p8_1"	Scene Off 1	int
"/p/p9_1"	HVAC On 1	int
"/p/p10_1"	HVAC Off 1	int
"/p/p11_1"	Scaling On 1	int
"/p/p12_1"	Scaling On 2 1	int
"/p/p13_1"	Scaling On 3 1	int
"/p/p14_1"	Scaling Off 1	int
"/p/p15_1"	Color On 1	color
"/p/p16_1"	Color Off 1	color
"/p/p17_1"	Output 1	int
"/p/p3_2"	Luminance Level 2	int
"/p/p5_21_2"	Luminance Level 2 1 2	int
"/p/p5_22_2"	Luminance Level 2 2 2	int
"/p/p5_31_2"	Luminance Level 3 1 2	int
"/p/p5_32_2"	Luminance Level 3 2 2	int

url	name	param type
"/p/p5_33_2"	Luminance Level 3 3 2	int
"/p/p6_2"	Luminance Levels 2	int
"/p/p7_2"	Scene On 2	int
"/p/p8_2"	Scene Off 2	int
"/p/p9_2"	HVAC On 2	int
"/p/p10_2"	HVAC Off 2	int
"/p/p11_2"	Scaling On 2	int
"/p/p12_2"	Scaling On 2 2	int
"/p/p13_2"	Scaling On 3 2	int
"/p/p14_2"	Scaling Off 2	int
"/p/p15_2"	Color On 2	color
"/p/p16_2"	Color Off 2	color
"/p/p17_2"	Output 2	int
"/p/pl_1_4"	On/Off (luminance) 4	int
"/p/pl_2_4"	Sleep Period (luminance) 4	int
"/p/pd1_3"	Sleep Period (battery value) 3	int
"/p/pd2_3"	Battery Curve 3	int
"/p/pd3_3"	Battery 3	int
"/p/pd4_3"	Battery Alarm Level 3	int

**Table 14:** Parameters

### 7.2.1. Parameter Switch On delay 1

PRD switch on delay [sec]

Example: 0

used data range: [0, 65000]

### 7.2.2. Parameter Switch Off Delay 1

PRD switch off delay [sec]

Example: 120

used data range: [60, 65000]

### 7.2.3. Parameter Luminance Level 1

MDL luminance level [Lux]

Example: 300

used data range: [1, 10000]

### 7.2.4. Parameter EBI 1

MDL brightness independency

Values:

- Yes : value 0
- No : value 1 **[Default]**

Example: 1

### 7.2.5. Parameter Luminance Level 2 1 1

Luminance 2 Levels, Level 1 [Lux]

Example: 1000

used data range: [300, 10000]

### 7.2.6. Parameter Luminance Level 2 2 1

Luminance Levels 2, Level 2 Channel: 1 [Lux]

Example: 100

used data range: [0, 300]

### 7.2.7. Parameter Luminance Level 3 1 1

Luminance 3 Levels, level 1 Channel: 1 [Lux]

Example: 1000

used data range: [400, 10000]

### 7.2.8. Parameter Luminance Level 3 2 1

Luminance 3 Levels, Level 2 Channel: 1 [Lux]

Example: 300

used data range: [200, 400]

### 7.2.9. Parameter Luminance Level 3 3 1

Luminance Levels 3, Level 3 Channel: 1 [Lux]

Example: 50

used data range: [1, 200]

### 7.2.10. Parameter Luminance Levels 1

Number of Luminance Levels 1

Values:

- Brightness Independent : value 0
- 1 : value 1 **[Default]**
- 2 : value 2
- 3 : value 3

Example: 1

### 7.2.11. Parameter Scene On 1

Scene number to send when On

Example: 1

used data range: [1, 64]

### 7.2.12. Parameter Scene Off 1

Scene number to send when Off

Example: 2

used data range: [1, 64]

### 7.2.13. Parameter HVAC On 1

HVAC value to send when On

Values:

- Auto : value 0
- Comfort : value 1 **[Default]**
- Standby : value 2
- Economy : value 3
- Building protection : value 4

Example: 1

### 7.2.14. Parameter HVAC Off 1

HVAC value to send when Off

Values:

- Auto : value 0
- Comfort : value 1
- Standby : value 2 **[Default]**
- Economy : value 3
- Building protection : value 4

Example: 2

### **7.2.15. Parameter Scaling On 1**

Scaling value to send for lumninance level 1 (On)

Example: 200

used data range: [0, 255]

### **7.2.16. Parameter Scaling On 2 1**

Scaling value to send for lumninance level 2 (On)

Example: 75

used data range: [0, 255]

### **7.2.17. Parameter Scaling On 3 1**

Scaling value to send for lumninance level 3 (On)

Example: 50

used data range: [0, 255]

### **7.2.18. Parameter Scaling Off 1**

Scaling value to send on Off

Example: 0

used data range: [0, 255]

### **7.2.19. Parameter Color On 1**

Color value to send for On (RGB), default white

Example: #FFFFFF

### **7.2.20. Parameter Color Off 1**

Color value to send for off (RGB), default black

Example: #000000

### **7.2.21. Parameter Luminance Level 2**

MDL luminance level [Lux]

Example: 300

used data range: [1, 10000]

### **7.2.22. Parameter Luminance Level 2 1 2**

Luminance 2 Levels, Level 1 Channel:2 [Lux]

Example: 1000

used data range: [300, 10000]

### **7.2.23. Parameter Luminance Level 2 2 2**

Luminance Levels 2, Level 2 Channel:2 [Lux]

Example: 100

used data range: [0, 300]

### **7.2.24. Parameter Luminance Level 3 1 2**

Luminance 3 Levels, level 1 Channel:2 [Lux]

Example: 1000

used data range: [400, 10000]

### **7.2.25. Parameter Luminance Level 3 2 2**

Luminance 3 Levels, Level 2 Channel:2 [Lux]

Example: 300

used data range: [200, 400]

### **7.2.26. Parameter Luminance Level 3 3 2**

Luminance Levels 3, Level 3 Channel:2 [Lux]

Example: 50

used data range: [1, 200]

## 7.2.27. Parameter Luminance Levels 2

Number of Luminance Levels Channel:2

Values:

- Brightness Independent : value 0
- 1 : value 1 **[Default]**
- 2 : value 2
- 3 : value 3

Example: 1

## 7.2.28. Parameter Scene On 2

Scene number to send when On

Example: 1

used data range: [1, 64]

## 7.2.29. Parameter Scene Off 2

Scene number to send when Off

Example: 2

used data range: [1, 64]

## 7.2.30. Parameter HVAC On 2

HVAC input

Values:

- Auto : value 0
- Comfort : value 1 **[Default]**
- Standby : value 2
- Economy : value 3
- Building protection : value 4

Example: 1

## 7.2.31. Parameter HVAC Off 2

HVAC value to send when Off

Values:

- Auto : value 0
- Comfort : value 1
- Standby : value 2 **[Default]**

- Economy : value 3
  - Building protection : value 4
- Example: 2

### **7.2.32. Parameter Scaling On 2**

Scaling value to send for lumninance level 1 (On)

Example: 200

used data range: [0, 255]

### **7.2.33. Parameter Scaling On 2 2**

Scaling value to send for lumninance level 2 (On)

Example: 75

used data range: [0, 255]

### **7.2.34. Parameter Scaling On 3 2**

Scaling value to send for lumninance level 3 (On)

Example: 50

used data range: [0, 255]

### **7.2.35. Parameter Scaling Off 2**

Scaling Off

Example: 0

used data range: [0, 255]

### **7.2.36. Parameter Color On 2**

Color value to send for On (RGB), default white

Example: #FFFFFF

### **7.2.37. Parameter Color Off 2**

Color value to send for off (RGB), default black

Example: #000000

### **7.2.38. Parameter On/Off (luminance) 4**

Luminance Enable.

Values:

- Enable : value 1 **[Default]**
- Disable : value 2

Example: 1

### 7.2.39. Parameter Sleep Period (luminance) 4

Sleep period in Seconds, after each period the device wakes up and sends the lux value.

Values:

- 1 minute : value 60
- 5 minutes : value 300
- 10 minutes : value 600
- 15 minutes : value 900
- 30 minutes : value 1800
- 1 hour : value 3600 **[Default]**

Example: 3600

### 7.2.40. Parameter Sleep Period (battery value) 3

Sleep period in Seconds, after each period the device wakes up and creates and sends the battery value.

Values:

- 1 minute : value 60
- 5 minutes : value 300
- 10 minutes : value 600
- 15 minutes : value 900
- 30 minutes : value 1800
- 1 hour : value 3600 **[Default]**
- 2 hours : value 7200
- 4 hours : value 14400
- 8 hours : value 28800
- 16 hours : value 57600
- 24 hours : value 86400

Example: 3600

### 7.2.41. Parameter Battery Curve 3

Curve selection, so that the battery percentage can be calculated according the used battery type.

Values:

- Zinc-Carbon (R6) : value 1

- Alkaline (LR6) : value 2 **[Default]**
- Li-FeS2 (FR6) : value 3

Example: 2

### 7.2.42. Parameter Battery Alarm Level 3

send boolean on minim level reached

Example: 10

used data range: [5, 100]